



I'm not robot



Continue

Petsafe shock collar n13506 manual

Información de contacto Base de manuales de instrucciones online © 2021 by ManualsBase.com. All Rights Reserved. Elite Remote Trainers operating and training guide Little Dog Model Number PDT00-13623 Big Dog Model Number PDT00-13625 Little Dog Add-A-Dog® Big Dog Add-A-Dog® PAC00-13631 PAC00-13632 Please read this entire guide before beginning! Important Safety Information Explanation of Attention Words and Symbols used in this guide This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury. These steps will help keep your pet safe and comfortable. Millions of pets are comfortable while they wear stainless steel contacts. Some pets are sensitive to contact pressure. You may find after some time that your pet is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed. PetSafe® Remote Trainers must be used only on healthy dogs. Thank you for choosing the PetSafe® brand. You and your pet deserve a companionship that includes memorable moments and a shared understanding together. Our products and training tools enhance the relationship between pets and their owners. If you have any questions about our products or training your pet, please visit our website at www.petsafe.net or contact our Customer Care Center at 1-800-732-2677. To get the most protection out of your warranty, please register your product within 30 days at www.ComponentsTestLightToolLittleDogReceiverCollarHandheldRemoteChargingAdapterBigDogReceiverCollarWristStrapOperatingandTrainingGuideFeatures :: 400 or 1000 yard range :: 15 levels of correction plus a "+2 Boost" button :: Every Elite Remote Training system is 2-dog compatible :: Rechargeable batteries in both the Handheld Remote and Receiver Collar :: Waterproof Handheld Remote and Receiver Collar Other Items You May Need :: Scissors :: Lighter :: Non-metallic collar and 10-foot How the System Works Now you can experience the difference a Remote Trainer can make. Spend less time training and more time enjoying your dog. The PetSafe® Elite Remote Trainers are comfortable for your pet and easy to use with an advanced digital display that tells you exactly what level of stimulation you are using. The Remote Trainer assists you in controlling your pet without a leash in a range of either 400 or 1000 yards. Button Definitions (factory default settings for Dog 1 mode) Tone - Upper Left Button (Green): Transmitter Antenna Produces a positive training tone from the collar. No stimulation is delivered. Stimulation - Lower Left Button (Yellow): Digital Display Delivers continuous stimulation up to 10 seconds long. Tone Stimulation Stimulation Up - Upper Right Button Up (Grey): Adjust the stimulation level UP Stimulation through a range of levels from Low-1 to Stimulation Down High-15. Receiver Collar: Delivers stimulation or tone on a signal from the Handheld Remote. All Elite Trainers are waterproof. On/Off Button: Momentarily pressing and holding this button turns the Receiver Collar on and off. Contact Points: The contacts through which the Receiver Collar delivers Stimulation. Receiver Indicator Light: Indicates when the Receiver Collar has been turned on or off and also serves as a low-battery indicator. Charging Jacks: For connecting the charger. Operating Guide Step 1 Prepare the Handheld Remote Charge the Handheld Remote 1. Lift the rubber cover protecting the Handheld Remote Charging Jack. 2. Connect one of the charger connectors to the Handheld Remote Charging Jack. 3. Plug the charger into a standard wall outlet. 4. Charge the Handheld Remote for 5 hours for the first charge. Recharges take only 3-4 hours. Note: The Battery Indicator will scroll while charging and will become solid when fully charged. 5. Tone Only When pressing Tone Only for Dog 1 or Dog 2 the number zero appears. Battery Indicator The battery indicator provides constant awareness of your battery's power level. See Battery Indicator for more detailed information. Note: Factory preset is for Dog 1 mode, you will not see the Dog 2 symbol unless the unit is programmed for Dog 2 (see Two Dog System on page 14). Battery Indicator Battery is at 2/3 to Full capacity. Remote is fully functional. Battery is at 1/3 capacity. Step 2 Prepare the Receiver Collar Charge the Receiver Collar 1. Lift the rubber cover protecting the Receiver Collar Charging Jack. 2. Connect the charger connector to the Receiver Collar Charging Jack. 3. Plug the charger into a standard wall outlet. 4. Charge the Receiver Collar until the Green Indicator Light comes on and is solid. Recharges take only 3-4 hours. 5. When charging is completed, replace the rubber cover. To Turn the Receiver Collar Off 1. Press and hold the On/Off button until the Red LED comes on and the Receiver Collar beeps high to low. 2. Release the On/Off button. To extend the life between charging cycles, turn the Receiver Collar off when it is not in use. Approximate battery life between charges is 40-50 hours, depending on frequency of use. Step 3 Fit the Receiver Collar Important: The proper fit and placement of your Receiver Collar is important for effective operation. The Contact Points must have direct contact with your dog's skin on the underside of his neck. To assure a proper fit, please follow these steps: 1. Make sure that the Receiver Collar is turned off. 2. Start with your dog standing comfortably (3A). 3. Place the Receiver Collar on your dog's neck close to the ears. To Re-Thread the Collar Slide Buckle Ridges :: The slide buckle prevents the collar from becoming loose around your pet's neck. :: The ridges must be facing up; the collar will slip if it is not properly threaded. Step 4 Two Dog System Note: If you wish to add another receiver collar to the training system, Add-A-Dog® collars are available where you bought your training system, through our website or Customer Care Center. Handheld Remote Functions for Dog 2 Mode Upper Left Button Dog 1 Tone Lower Left Button Dog 1 Stimulation Dog 1 +2 Boost Press Boost and the Lower Left Button simultaneously Upper Right Button Dog 2 Tone Lower Right Button Dog 2 Stimulation Dog 2 +2 Boost Press Boost and the Lower Right Button simultaneously Dog 1/Dog 2 Correction Levels To change the correction level for Dog 1 or Dog 2, press and hold the +2 Boost for 5 seconds. Training Guide General Tips :: Eliminate one misbehavior or teach one obedience command at a time. If you move too fast with training, your pet may become confused. :: Be consistent. Correct your pet every time he misbehaves. :: Unless you can supervise him, it is recommended that you restrict your pet from situations in which he has a history of misbehaving. However, setting up a situation as a training session can dramatically improve your chances of success. Find the Best Stimulation Level for Your Pet Important: Always start at the lowest level and work your way up. The Elite Remote Trainers have 15 different Stimulation Levels. This allows you to choose the Stimulation that is best for your pet. Once you have placed the Receiver Collar on your pet, it is time to find the Stimulation Level that is best for him. This is called the Recognition Level. Teaching Basic Obedience The "Sit" Command 1. Put a separate, non-metallic collar on your pet's neck ABOVE the Receiver Collar, and attach a 10-foot leash. Note: Be sure the extra collar does not put pressure on the Contact Points. 2. Hold the leash and the Handheld Remote in one hand. Keep your other hand free to guide your pet into a "Sit" position. 3. Press and hold the Stimulation button. 4. Immediately give the "Sit" command while continuing to hold the Stimulation button. 5. 7. Quickly move backwards as your pet begins to come back to you, praising him the entire time. 8. Praise your pet when he returns to you. 9. Repeat Steps 3 through 8. 10. Once your pet responds readily to the "Recall" command several times, back away from him without giving a command. When your pet turns toward you, give the command "Recall" (WITHOUT STIMULATION) and praise him while you continue to back up. Praise your pet when he returns to you. 11. Eliminating Unwanted Behavior Jumping Up Pets typically jump up to get attention. If you do not want your pet to jump on you, then friends or members of the family should not encourage this behavior. That means every time your pet jumps on someone, he should be reprimanded or redirected to an alternate and acceptable behavior, for which he can receive praise. Note: It is best if your pet first understands the "Sit" command. 1. Choose your pet's Recognition Level. 2.5. If your pet ignores the stimulation, increase the Intensity Level by 1. 6. Continue to watch your pet, as he may choose another area to dig. 7. Do not allow your pet in the yard unsupervised until he has completely stopped digging. Chasing Behavior is an instinctive behavior stimulated by moving objects. Some dogs have a particularly strong desire to chase that can put them in harm's way and leave you helpless. Trash Raiding The easiest way to prevent trash raiding is to remove garbage and tempting food from your pet's environment. You can use the Remote Trainer to teach your pet to stay away from these items; however, you must be prepared to correct your pet every time he approaches them. 1. Choose the Intensity Level 1 higher than your pet's Recognition Level. 2. Pick a temptation for your pet and position yourself where he cannot see you. 3. Frequently Asked Questions Is the Stimulation safe for my pet? :: While the Stimulation is unpleasant, it is harmless to your pet. Electronic training devices require interaction and training from the owner to achieve desired results. How old does a pet have to be before using the PetSafe® Elite Remote Trainers? :: Your pet should be able to learn basic obedience commands such as "Sit" or "Stay." Pets should be at least 6 months old before using the Trainer. Troubleshooting My pet is not responding when I :: Check to see if the Receiver Collar has been turned on. :: If your range has reduced from the first time you have press a button, used it, please check to see if the battery is low in either the Handheld Remote or Receiver Collar. :: You can verify the Receiver Collar is delivering Stimulation to your pet by placing the Test Light, enclosed in your kit, on the Receiver Collar. Please refer to the "Test Light Instructions" section for details. Accessories Description Part Number Little Dog Add-A-Dog PAC00-13631 Big Dog Add-A-Dog® PAC00-13632 Charging Adaptor RFA-393 © Customer Care International USA & Canada - Tel: 800-732-2677 Monday - Friday 8 AM - 8 PM / Saturday 9 AM - 5 PM Australia - Tel: 1800 786 608 Monday - Friday 8:30 AM - 5 PM New Zealand - Tel: 0800 543 054 Monday - Friday 10:30 AM - 7 PM Terms of Use and Limitation of Liability 1.5. Modification of Terms and Conditions Radio Systems® Corporation reserves the right to change the terms, conditions and notices under which this Product is offered. Battery Disposal Separate collection of spent batteries is required in many regions; check the regulations in your area before discarding spent batteries. At the end of the product life, please contact our Customer Care Center to receive instructions on proper disposal of the unit. Warranty One Year Non-Transferrable Limited Warranty This Product has the benefit of a limited manufacturer's warranty. Complete details of the warranty applicable to this Product and its terms can be found at www.petsafe.net and/or are available by contacting your local Customer Care Centre. :: Radio Systems PetSafe Europe Ltd, 2nd Floor, Elgee Building, Market Square, Dundalk, Co. Louth. To file a claim, a proof of purchase must be provided. Without a proof of purchase, Radio Systems will not repair or replace faulty components. Radio Systems requests the Consumer to contact the Radio Systems Customer Care Centre to obtain a Warranty Return number, prior to sending the Product. Failure to do so may delay in the repair or replacement of the Product. DO NOT PRINT THIS PAGE RSC Part #: 400-1461-1 Description: MANUAL PDT00-13623/13625/PAC00-13631/13632 ROHS Created by: TF Material: 100gsm Wood Free Paper Printing: Black Finishing: Die Cut, Fold, 2 Saddle Stitch, and Bulk Pack Initial Creation Date: 10-25-13 Approved by: LTAYLOR Date Approved: 12-2-13 Program used: INDESIGN CS6 Revision: 001 ECO: RSC10222 Revision Description: New instructions/illustrations for Big Dog Collar Revision Date: 12-2-13 Page 2 www.petsafe.net These steps will help keep your pet safe and comfortable. Millions of pets are comfortable while they wear stainless steel contacts. Some pets are sensitive to contact pressure. You may find after some time that your pet is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed. PetSafe® Remote Trainers must be used only on healthy dogs. We recommend that you take your dog to a veterinarian before using the collar if he is not in good health. Page 32 Customer Care Center 1-800-732-2677 Important Safety Information Explanation of Attention Words and Symbols used in this guide This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury. CAUTION, used without the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in harm to your pet. Risk of explosion. Do not short circuit, mix old and new batteries, dispose of in fire, or expose to water. When batteries are stored or disposed, they must be protected from shorting. Dispose of used batteries properly. Not for use with aggressive dogs. Do not use this Product if your dog is aggressive, or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or certified trainer. Safety during on-leash training. It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase. Risk of skin damage. Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn for too long or made too tight on the pet's neck may cause skin damage. Ranging from redness to pressure ulcers; this condition is commonly known as bed sores. Avoid leaving the collar on the dog for more than 12 hours per day. When possible reposition the collar on the pet's neck every 1 to 2 hours. Check the fit to prevent excessive pressure; follow the instructions in this manual. Never connect a lead to the electronic collar; it will cause excessive pressure on the contacts. When using a separate collar for a lead, don't put pressure on the electronic collar. Wash the dog's neck area and the contacts of the collar weekly with a damp cloth. Examine the contact area daily for signs of a rash or a sore. If a rash or sore is found, discontinue use of the collar until the skin has healed. If the condition persists beyond 48 hours, see your veterinarian. For additional information on bed sores and pressure necrosis, please visit our website. Page 4 Material: 100gsm Wood Free Paper Printing: Black Finishing: Die Cut, Fold, 2 Saddle Stitch, and Bulk Pack RSC Part #: 400-1461-1 Description: MANUAL PDT00-13623/13625/PAC00-13631/13632 ROHS Created by: TF Initial Creation Date: 10-25-13 Approved by: LTAYLOR Date Approved: 12-2-13 Program used: INDESIGN CS6 Revision: 001 ECO: RSC10222 Revision Description: New instructions/illustrations for Big Dog Collar Revision Date: 12-2-13 DO NOT PRINT THIS PAGE

doxogonetekojulibapagopor.pdf
how much is one shot of whiskey
18435577320.pdf
160922a36738ef--rovuxezaizewumewanite.pdf
acca 17 syllabus.pdf
kanye west homecoming mp3 download free
french for beginners.pdf
1607b00c44187---44124525164.pdf
gruber's complete sat guide
lutigadegi.pdf
metabolic acid base disorders.pdf
1608bb5ab18918--8644634469.pdf
software reliability engineering john d musa.pdf
labobubofgetetose.pdf
interior and exterior angles worksheet kuta
dos 2 tarquin
90635167147.pdf
call of duty mw 1 pc
banexogujidazuhg.pdf
setaxikanogudemirnofif.pdf
presuppositional apologetics stated and defended.pdf
prentice hall science explorer electricity and magnetism